
## ARROW ANCHOR, DRYWALL ANCHOR


## Mounting in drywall



1. Knock the anchor into the drywall.



2. Screw a drywall screw, Ø 3.5 to 3.9 mm.



3. The anchor expands at the back and secures the object to be installed.

